


Recording with Polsen Wireless Microphone Kit

The Polsen Wireless microphone kit allows you to wirelessly record audio using a video recorder such as an iPhone/iPad or camcorder with an external microphone jack. It does **not** work with a Flip camera. **Important!** Make sure that the batteries in both the transmitter and receiver have enough power to last during your recording. A new battery lasts up to six hours. When the POWER to the receiver and transmitter are ON, the indicator will light red but there is no gauge to measure remaining life.



If using an iPad or iPhone, connect the TRS adapter cable to the curly audio jack.



Snap the receiver shoe into the cold shoe mount on the iPad case.



It is important that you test your audio!

Check the following:

- 3.5mm audio cords are securely plugged in on the iPad, receiver and transmitter units
- Wireless receiver and transmitter units are on the same channel
- Power switch on wireless receiver unit and transmitter unit are in the "on" position.
- Test your audio at a distance carrying the transmitter with you.

